



Griform Innovations[®], Inc. Shower Corner Seat Installation

Backing should be installed between the wall studs in the location where the shower seat is to be located.

The Griform Shower Seat will have a ledger that you will put your fasteners through and into the shower wall backing. (Make sure fasteners are long enough to attach the shower seat ledger, through the shower wall, and into the backing.)

Prior to tightening the seat clean seat with denatured alcohol and apply a thin bead of silicone along the ledger, then finish tightening your fasteners.

To help with any standing water, we suggest a **very** slight forward angle be made upon installing the seat. The seat is designed for water to shed off, but this would also ensure water to flow off.